

Shoulder bags



Event Messenger™

A professional level of discretion for the enthusiast event photographer

The Event Messenger Series is for enthusiast photographers who carry camera gear, a laptop or tablet and some small items, offering a slim profile and innovatively quick, quiet access.

Built to fit a complete camera kit, streamlined and classically detailed, the Event Messenger is lightweight, and easy to carry and work out of. The wide

gusseted main compartment offers full access to gear and includes an adjustable padded divider system to organise a kit in multiple configurations.

Keep your gear secured with the top flap positioned by hook/loop fasteners, or fold them back to work in a quieter mode, for a professional level of discretion as you photograph an event.

Use the front zippered pocket to keep accessories and small personal items organised and within reach. Includes a separate padded compartment for a laptop or tablet. Additional features include an adjustable shoulder strap, stretch side pockets and a grab handle.

The Event Messenger is available in Mica.

FEATURES

Discreet, streamlined messenger design

Quiet-mode flap

Easy access main compartment

Front zippered pocket

Padded tablet compartment

Comfortable shoulder strap with wide webbing & non-slip patch

Stretch side pockets

Grab handle

Back slash pocket

BENEFITS

- ▶ Disguises the fact that the shoulder bag is built to carry and protect a complete camera kit
- ▶ Provides hook/loop fasteners that may be folded back to go from maximum-security mode to quiet mode
- ▶ Offers padded and adjustable divider system to easily customise camera gear
- ▶ Provides organised storage space for accessories and small personal items
- ▶ Offers protective and separate storage space for a tablet (150 only)
- ▶ Adjusts to fit over shoulder or across body; includes a sliding pad for extra support
- ▶ Offer additional space for quick-grab items
- ▶ Provides an additional carrying option
- ▶ Offers quick-access storage for a manual or other small personal items

Specifications

	Event Messenger™ 100	Event Messenger™ 150	Event Messenger™ 250
INTERNAL (W x D x H)	20 x 9 x 16.8 cm (7.9 x 3.5 x 6.6 in.)	29.5 x 10 x 21.8 cm (11.6 x 3.9 x 8.6 in.)	35 x 12 x 34.5 cm (13.8 x 4.7 x 13.6 in.)
EXTERNAL (W x D x H)	22 x 14 x 21.5 cm (8.7 x 5.5 x 8.5 in.)	34.3 x 15.8 x 26.6 cm (13.5 x 6.2 x 10.5 in.)	38.8 x 18.8 x 29.8 cm (15.3 x 7.4 x 11.7 in.)
WEIGHT	0.4 kg (0.9 lb)	0.4 kg (0.9 lb)	0.8 kg (1.8 lb)
FITS	Compact DSLR with attached 18–55 lens, 1–2 additional lenses/flash, accessories	Standard DSLR with attached lens, 2–3 additional lenses/flash, accessories, tablet computer	Standard DSLR attached lens, 3–4 additional lenses/flash, accessories, 13" laptop
SKU	680707	680706	680705
RRP	\$49.00	\$65.00	\$79.00

INFORMATION DATED: 2 February 2012



maxwell
INTERNATIONAL AUSTRALIA

SUPPORTED LOCALLY BY MAXWELL INTERNATIONAL AUSTRALIA

visit 12/11-21 Underwood Road, Homebush NSW 2140
offices also in Melbourne, Brisbane, Adelaide, Perth
phone 1300 882 517
fax 1300 882 519

email
product support
website
print-resolution images

sales@maxwell.com.au
www.maxwell.com.au/support
www.lovepro.com
highres.maxwell.com.au/lovepro